

# Fragile Planet Ltd

Unit 14  
Radfords Field  
Maesbury Road  
Oswestry  
SY10 8RA  
T: 01691 672869  
E: [TonyGray@fragile-planet.co.uk](mailto:TonyGray@fragile-planet.co.uk)  
W: [www.fragile-planet.co.uk](http://www.fragile-planet.co.uk)

Company Number: 5274350  
VAT Registration 869 5030 00

Roof Assembly Instructions

December 2009

## **Components**

### *Wood*

2 Long Inner Rails 15mm x 15mm  
2 Short Inner Rails 15mm x 15mm  
2 Outer Straight Sides 312mm x 25mm  
2 Ends with holes for ventilation 450mm x 25mm – Mesh fitted  
2 Ply Roof panels

### *Nails*

16 40mm Nails  
20 10mm Gimp Pins  
12 20mm Gimp Pins

Aluminium sheet  
2 small squares of wire mesh

## **Instructions**

Attach the 2 Outer straight sides to the 2 Ends – leaving the wire mesh on the inside having first nailed wire mesh squares over the air vent holes.

Ensure that the 2 Outer sides are mounted inside the Ends, see the diagram below. Use the 40mm nails

Attach the Ply roof panels to the Ends.

Nail the Aluminium Sheet to the Roof using the 10mm gimp pins.

Nail the inner rails to the inside of the roof using the 20mm gimp pins, leaving a 50cm gap from the bottom of the roof to the bottom of the rails. This is the overlap over the crown board.

This roof needs an external preservative

